



INSTALLATION INSTRUCTIONS

PART No.

FB21114

General Tube Doors

Tube Door Clamp Mirrors



REQUIRED TOOLS

4mm Allen
8mm Wrench

KIT CONTAINS

Clamp Mirror (Top)
Clamp Mirror (Bottom)
Cap Screw

QTY

2
2
4

1) LOOSELY INSTALL

With two of the included screws, and a mirror top and bottom, loosely install the mirror so that it sits upright unassisted.



With an 8mm wrench, turn the hex nut behind the mirror clockwise so that the mirror doesn't rotate or fall.

2) ADJUST TO PREFERENCE

Get inside your vehicle and move and twist the mirror into your desired position.



Repeat on the opposite side.

3) TIGHTEN THE BOLTS

With a 4mm Allen key, tighten down the 2 screws so that the mirror doesn't slide or rotate on the tube.

4) ENJOY YOUR NEW FISHBONE OFFROAD HEADLIGHT GUARDS!

